

HIT00323 ADJUSTABLE SQUAT RACK / STANDARD



OWNER'S MANUAL

PART LIST

PART NO:	DESCRIPTION	Q'TY
1.	LEFT&RIGHT VERTICAL FRAME	2
2.	REAR BOTTOM CONNECTION FRAME 50*50MM	1
3.	REAR BOTTOM CONNECTION FRAME 44*44MM	1
4.	ADJUSTABLE BARBELL HOLDER	2
5.	HEX BOLT M10*70	6
6.	WASHER Φ10	12
7.	NYLON NUT M10	6



STEP 1

- 1. CONNECT (1) AND (3) WITH (5,6,7);
- 2. CONNECT (1) AND (2) WITH (5,6,7);
- 3. INSERT (3) INTO (2), ADJUST WIDTH ACCORDING TO NEEDS
- 4. INSERT (4) INTO (1), ADJUST HEIGHT ACCORDING TO NEEDS.

NOTE: PLEASE FASTEN ALL BOLTS BEFORE USING THIS RACK!