



HIT SPORT

MCS024

PORTABLE BASKETBALL HOOP MANUAL



Please identify parts and read this manual carefully before installation.
We're looking forward to hearing from you on any warranty queries or suggestions!

SAFETY INSTRUCTIONS

FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE AND WILL VOID WARRANTY.

Do not stand the basketball hoop upright until the base is filled with water or sand, as system may tip over causing injuries.

Do not use system during windy and/or severe weather conditions the basketball hoop is easy to tip over, please move the system indoors.

Must tip the system for ward and rest the rim on as urface before adjusting the height.


- Owner must ensure that all players know and follow these rules for safe operation of the system.
- Check entire box and inside all packing material for parts and additional instruction material.
- Before beginning assembly, read the instructions and identify parts according to this manual.
- Proper and complete assembly, use, and supervision are essential for proper operation and to reduce the risk of accident or injury.
- A high probability of serious injury exists if this system is not installed, maintained, and operated properly.

- Two capable adults are recommended for this operation.
- Check base regularly for leakage. Slow leaks could cause system to tip over unexpectedly.
- Seat the pole sections properly(if applicable). Failure to do so could allow the pole sections to separate during play and transport of the system.
- Climate, corrosion, or misuse could result in system failure.
- This equipment is intended for home recreational use only and not excessive competitive play.
- The life of your basketball pole depends on many conditions. The climate, placement of the pole, Location of the pole, exposure to corrosives such as pesticides, herbicides, or salts are all important.
- If technical assistance is required, contact Customer Service.

Most injuries are caused by misuse and not following instructions. Use caution when using this system.

GET TO KNOW THE BASIC PARTS


BACKBOARD



1



2




3



4

BASE




5



7



10



6




8



9

GET TO KNOW THE BASIC PARTS

SUPPORT POLE



W



X




Y

SPARE PARTS



M12X180mm



M12X180mm



M12X180mm



M10X120mm



M8X90mm



M8X100mm




M8X30mm



M12X180mm



M12X180mm



M10X100mm




M10X100mm



M8X45mm




M8X20mm



M8X25mm

GET TO KNOW THE BASIC PARTS

TOP SUPPORT POLE




TOOLS NEEDED



INSTALLATION STEPS

BACKBOARD


Needed Parts



1



2




3



21





15



INSTALLATION STEPS

BACKBOARD


Needed Parts





INSTALLATION STEPS

BACKBOARD

2.2



Needed Parts



INSTALLATION STEPS

BACKBOARD

2.3

Needed Parts



11



25



INSTALLATION STEPS

BACKBOARD

2.4


Needed Parts



13







27




INSTALLATION STEPS

BACKBOARD

2.4




BASE





INSTALLATION STEPS

BASE



As shown on above picture, insert wheel shaft (10) into wheel (9), base (5) and wheel bracket (26) one by one.



INSTALLATION STEPS

BASE



7



28

Use screws to place DD on U3, U4 as shown

