
HIT SPORT


TABLE TENNIS TABLE INSTRUCTION

Product code:MSC004



Assembly Instructions

1. Carefully lay both table tops flat and face down on a soft surface. Unlock and unfold pre-assembled table top, using two iron plates to fix 'T' leg into designated position and ensure marking tape lines up on each side, see figure 1.



Preparation for use


- 1. Open the carton and check to ensure all accessories and fittings are complete.
- 2. Install 'T' leg according to figure 1 above.
- 3. Tighten all screws and turn table up right way ready for use.

Care and Maintenance for use of your Table

- 1. This item is very heavy. A minimum of two persons should be used to assemble or move the table.
- 2. Two pieces of table top have to be separated before folding or opening.
- 3. Do not place table outside for playing.
- 4. Do not beat on surface of table with paddle.
- 5. Do not place hot goods on table top.
- 6. Do not place heavy goods on table to avoid distortion.
- 7. Do not use table for any other exercise other than table tennis.
- 8. Do not move table around quickly on rugged ground.
- 9. Keep table in a dry, well ventilated area to avoid exposure to sun and rain, which will warp the table.
- 10. All wheels and feet can be adjusted slightly to ensure level playing surface.


PLEASE READ ALL THE INSTRUCTIONS BEFORE ASSEMBLY (PAGE 2)

Operation Method




Release the lock before opening the Table Tennis Table and lock it prior to folding the table.

Leg HingeWheel Operation



Straighten hinge when using table and collapse hinge to fold table. Lock wheel tightly when using table and unlock for moving and storing.

Height Adjusting Method



The wheel height can be adjusted to a maximum of 15mm. The foot height can also be adjusted to a maximum of 15mm.